

SR INJECTOR

Injector for Marisol SR – soot remover powder


DATA SHEET

ENGINE



The simplest way to dose MARISOL SR into boiler fire-side:

- open service air supply valve.
- fill dosing pot slowly with MARISOL SR



MARITECH – Marine Technologies AB

P.O.Box 143, S-291 22 Kristianstad, SWEDEN · Tel. Int. +46 44 106040, Fax. Int. +46 44 106440
e-mail: marisol@maritech.se www.marisol.nu

INFORMATION OF OUR PRODUCTS ARE GIVEN COMPLETELY FREE OF UNDERTAKING.
APPLICATION LIES OUT OF OUR CONTROL AND WE CANNOT ACCEPT ANY RESPONSIBILITY FOR THE RESULTS

2005-08-22